

## LISTAGEM DE BIO FLEX NOVOS/ IMPORTADOS COM CONECTORES ORIGINAIS.

- **Bio Flex TY (Toyota)**



- 

- Corolla a partir de 2003.

- Fielder.

- Amry v6.

- RAV-4.

- **Bio Flex HD (Honda)**



- 

- Civic a partir de 2000/ New Civic.

- Honda Fit todos.

-New Fit.

-Accord.

-Accord V6.

- CR-V.

- **Bio Flex EV6 – Somente 4 Cilindros.**



- Eco Sport 2.0 16V.
- Ranger importada.
- Ranger a partir de 2006.
- Novo Ford Focus ( Hatch/ Sedan).
- Ford F-250.
- Capitiva (GM).
- Jetta (VW).

- **Bio Flex Nippon Denso.**



- Tiida (Nissan).
- Traker 2.0 (gm).
- Subaru (todos).
- Polo 2.0/ Polo Sedan N 2.0.
- Bora a partir de 2003.
- New Beetle.
- Sportage (kia).
- Honda Civic até 1999.
- Corolla até 2002.
- Aud. A3
- Outland (Mitsubish).

- |  |
|--|
| - Hyunday ( todos) Tucson 2.0, v6/ sonata/ Santa Fé/ Vera Cruz/ Azera. |
| - Linha 307 a partir de 2006 (Peugeot).                                |
| - 407 sedan/ SW (peugeot).   |
| - Linha xsara a partir de 2006. (citroen).                             |
| - Berlingo ( citroen).   |
| - sentra (Nissan).   |